







Use this technique for the fabrication of short term (30 days), screw-retained single or multiple unit temporary restorations. This abutment is designed for chair-side restorations for developing optimal soft tissue contour and can be used when immediate load is indicated.

### component options

- PEEK temporary cylinder abutments
- .050" (1.25mm) hex driver
- torque wrench
- · direct coping screws



Make sure the implant prosthetic platform is free of bone and soft tissue. Snap the PEEK temporary cylinder abutment onto the implant using downward pressure.




Note: Snap feature creates a friction fit which will retain the abutment without the use of an abutment screw.



## 2 Mark the abutment

Evaluate inter-occlusal dimensions, angulation, and tissue contour. Mark the abutment for the required vertical reduction.



### 3 Modify the abutment

Remove the marked plastic abutment and place it on the abutment prepping handle using an .050" (1.25mm) hex driver and hand tighten. Modify the abutment for vertical clearance and gingival margins using a carbide or acrylic bur.



**Important** 


Maintain at least 3mm of abutment height to avoid damaging the abutment screw.






### 4 Try in the shell crown

Verify the implant prosthetic platform is free of bone and soft tissue. Irrigate the internally-threaded connection of the implant and dry. Snap the modified abutment onto the implant. Try in the appropriate polycarbonate/shell crown and modify as needed.



### 5 Create an access hole

Place the direct coping screw. Finger tighten using the knurled top or hand tighten using an .050" (1.25mm) hex driver. Create a screw access hole through the shell crown allowing the direct coping screw to pass through.



### Fill the shell crown

Mix acrylic or another material of choice and place inside the shell crown. Position the shell crown over the direct coping screw onto the modified plastic abutment.



### Note:

Undercuts on adjacent teeth should be blocked-out prior to this reline procedure.



### 7 Remove and polish the crown


Remove the direct coping screw and the relined shell crown using an .050" (1.25mm) hex driver. Place the screw-retained temporary crown onto the abutment prepping handle using the abutment screw. Contour and polish the temporary crown.






### 8 Re-seat the crown

Make sure the implant prosthetic platform is free of bone and soft tissue. Irrigate the internal connection of the implant and dry. Try in the prosthesis to confirm fit and contour. Modify as necessary and polish after making adjustments. Re-seat the prosthesis onto the implant and hand tighten the abutment screw using an .050" (1.25mm) hex driver.



### 9 Check and modify the temporary

Check the occlusion and contacts. There should only be light contact in centric occlusion and no contact in lateral excursions. Modify as necessary and polish after making adjustments.



# 10 Tighten the abutment screw

Tighten the abutment screws to 30 Ncm using a calibrated torque wrench and an .050" (1.25) hex driver.



### Note

Tightening the abutment screw to 30 Ncm is not recommended if the temporary is placed at the time of surgery.



### 11 Fill the screw access channel

Place a resilient material of choice (gutta-percha, silicone or temporary filling material) into the screw access channel. This allows for easy access to the abutment screw in the future. Fill the remainder of the channel using a composite resin material of choice. Take an x-ray for temporary prosthesis delivery records.







notes	





notes	





notes	

# **Direct Offices**

**BioHorizons USA** 

888-246-8338 or 205-967-7880

**BioHorizons Canada** 

866-468-8338

BioHorizons Spain +34 91 713 10 84

BioHorizons UK +44 (0)1344 752560

BioHorizons Germany

+49 761-556328-0

BioHorizons Chile +56 (2) 23619519 BioHorizons Italy 800-063-040

# **Distributors**

For contact information in our 90 countries, visit www.biohorizons.com



BioHorizons®, Laser-Lok®, MinerOss®, AutoTac®, Mem-Lok® and TeethXpress® are registered trademarks of BioHorizons. Unigrip™ is a trademark of Nobel Biocare AB. Zimmer® Dental ScrewVent® and Tapered ScrewVent® are registered trademarks of Zimmer, Inc. AlloDerm® and AlloDerm GBR® are registered trademarks of LifeCell Corporation. Grafton® DBM is a registered trademark of Medtronic, Inc. Spiralock® is a registered trademark of Spiralock Corporation. Pomalux® is a registered trademark of Westlake Plastics Co. Locator® is a registered trademark of Zest Anchors, Inc. Delrin® is a registered trademark of E.I. du Pont de Nemours and Company. Bio-Gide® is a registered trademark of Edward Geistlich Sohne AG Fur Chemische Industrie. Not all products shown or described in this literature are available in all countries. As applicable, BioHorizons products are cleared for sale in the European Union under the EU Medical Device Directive 93/42/EEC and the tissues and cells Directive 2004/23/EC. We are proud to be registered to ISO 13485:2003, the international quality management system standard for medical devices, which supports and maintains our product licences with Health Canada and in other markets around the globe. Original language is English. ©BioHorizons. All Rights Reserved.

This prosthetic technique module may contain references to the complete Prosthetic Manual (L02015). To download the full Prosthetic Manual, please visit www.biohorizons.com



shop online at store.biohorizons.com